

Switch ignition OFF.

Press and hold button [A] **87827**.

Switch ignition ON.

Keep button [A] depressed for 10 seconds.

Display will now read 0 and 'spanner' symbol will go out.

