

Telephone:
Fax:

Switch ignition OFF.
Press and hold button [A] **87827**.
Switch ignition ON.
Keep button [A] depressed for 10 seconds.
Display will now read 0 and 'spanner' symbol will go out.

