

31	Battery -
30	Battery +
M58	Central locking motor, boot lid/tailgate
M46	Central locking motor, driver
M47	Central locking motor, left rear
M48	Central locking motor, passenger
M49	Central locking motor, right rear
S226	Door contact switch, driver
S227	Door contact switch, left rear
S228	Door contact switch, passenger
S229	Door contact switch, right rear
EP3	Earth point location 3
EP4	Earth point location 4
EP5	Earth point location 5
EP6	Earth point location 6
F	Fuse
X28-IV	Fuse box/relay plate, fascia 2
15	Ignition switch - ignition ON
A11	Multifunction control module
A11-I	Multifunction control module 1

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

